



Josyoh

Overture
Adjustments manual

1. Keep the power on with the input level control set at minimum at least 15 minute before start to adjust.
2. Set your DVM onto the DC scale and place the negative lead on the chassis (ground). Place the positive lead on the pin "TEST 1". Rotate VR1 till you measure the voltage 0.5 to 0.55V on DVM.
Repeat same way on every test point "TEST 2, VR2" "TEST 3, VR 3" "TEST 4, VR 4".
3. Double or triple check the process 2 in order to get same voltage on all test point.

